

NOTES:

- 1. WHERE PIPE SIZE IS 2 1/2 " OR SMALLER,

 PROVIDE BALL VALVE IN LIEU OF BUTTERFLY VALVE.
- 2. PROVIDE THERMOMETERS AND PRESSURE GAUGES,
 PER SPECS.
- 3. INSTALL UNIONS IN PIPE LOCATION OUT OF WAY TO PULL COIL OUT
- 4. PROVIDE BALANCE METER IN THE SUPPLY

 PIPE FOR AHU COIL WITH 50 GPM OR MORE
- 5. PROVIDE BALL VALVE DRAIN VALVE AND DRAIN LINE TO FLOOR DRAIN.

RIES COIL PIPING DETAIL