
FILL VAT BLOCK
AT TIME SELECTED
BY USER
ALL COMPONENTS
RETURN STATUS
SINGLE TRAP
VIEW VAT AT
BLOCK TIME
(FILL, DISPOSAL,
RESET, MODIFICATION,
MOVE, MOVE PLATE)
VAT TYPE TRAPS IN
SEQUENCE TO DISPLAY
ADDITIONAL TRAPS IF
PRESENT


ALL COMPONENTS
RETURN STATUS
FILL VAT BLOCK
AT TIME SELECTED
BY USER
MULTIPLE TRAP

AIL